

M&P VISUAL METHOD/RISK/QUALITY SWANSEA UNIVERSITY TAPE & JOINTING

ALWAYS

Keep the working area clean & tidy.
Report to the Site Manager any defective work.
Screw any protruding screws into Metalwork.
Snag your own work before M&P final snag.
Use a sanding machine.
Always wear a mask when sanding.
Maintain the same high standards of a machine finish if installing any taping procedure by hand.

NEVER

Leave a mess on the floor or walls.
Attempt to finish over protruding Screws.
Cut corners.
Install beads out of level or plumb.
Ignore your responsibility to hand over your work to the painter snag free.

Please remember the 3 P's – Performance – Pride – Painter = QUALITY.....!



BEST PRACTICE

Always use 8 & 12 inch boxes for consistent quality.



BEST PRACTICE

Always use machine to bed tapes.

THINK SAFE – DANGER NEVER SLEEPS...!!